

get the best out of your wi-fi


Wi-fi signal in the home can be impacted by many things, furniture, mirrors, other electronic devices and thickness of walls can all reduce wi-fi signal and speed. Here are our 3 top tips to maximise the efficiency of your wi-fi router.

1. get full-fibre

Having full-fibre broadband will mean you can have multiple devices connected to your router without having to worry about slowdown due to sharing bandwidth or at peak times.

2. change your channel

You might experience slow speeds if your router is working on a channel that's too busy. The easiest way to switch to a better channel is simply by turning your router off and on again and it will automatically choose the best channel.



3. location, location, location

Don't put your router in a corner of the house or hidden from view. The signal from your router emits in all directions and could be sent outside your home, weakening your connection.

Don't put your router behind any solid objects like wardrobes, TVs and cupboards, or by a central wall, as this can block your wi-fi signal.

Do place your router in the middle of your house and off the floor, in a high place for maximum coverage.

Don't place your router in the kitchen due to many metal objects in this room which dissipates your signal. Glass from windows can also cause interference.